



North American
Specialty Laminations™
We've got you covered™

Mouldings Glossary of Terms

APRON

A piece of horizontal sash, window trim or casing applied to the wall immediately below the window stool; the apron serves to conceal the joint made by the sash or window frame sill and the interior wall surface

ARCHITRAVE

Moulding installed high above a window to add grandeur. Also helps disguise miter lines

ASTRAGAL

An interior moulding attached to a pair of doors or sash to prevent swing-through. Astragal ensures a tight fit where the doors meet; a flat astragal is one applied to the face of the meeting stile of the door and a T astragal is rabbeted (notched) to the approximate thickness of the swinging door

BACK BAND

A flat, decorative, or protective strip that's flush or raised above the surface; this moulding is similar to a panel moulding as well as an apron profile, and it's often used to trim mantels or cabinets

BAND MOULDING

Plain or sprung moulding that's applied where two surfaces come together at an angle; the profile usually consists of a bead and a cove; it's often used in place of crown where the walls and the ceiling meet

BASEBOARD

Also called wall base, this moulding is applied around the lower perimeter of the room along a finished floor

BASE CAP

A moulding applied atop a piece of base moulding flush with the wall to create a decorative look. It's sometimes used with baseboard. Base cap may also be used as a panel moulding or multipurpose profile

BASE SHOE

Also called shoe or floor mould, this narrow moulding provides a transition between finished floors and walls or cabinets; it protects the base from damage and conceals uneven lines or cracks where the base meets the floor. Shoe moulding may be used in place of quarter round

BEAD MOULDING

Plain or sprung moulding that's applied where two surfaces come together at an angle; the profile usually consists of a bead and a cove; it's often used in place of crown where the walls and the ceiling meet



North American
Specialty Laminations™
We've got you covered™

Mouldings Glossary of Terms

BRICK MOULD

A thick moulding used on an exterior door and/or window as a casing that joins the exterior facing and provides a surface for brick or other siding to butt against. It may be used to form a rabbet for screens, a storm sash or a combination door

CASED OPENING

An interior opening without a door but finished with jambs and casing

CASING

Trim used around door and window openings. Exterior casing trims the exterior of windows and doors. Interior casing trims the interior perimeters of windows and doors

CAULK

Waterproofing sealant for cracks and joints around window and doorframes

CHAIR RAIL

Interior moulding applied on the wall about a third of the way up from the floor, paralleling any base or crown moulding, and encircling the room. Originally used to prevent chairs from damaging the walls, it's now used more for decorative purposes. It can be made from more than one piece of moulding to build up the effect, especially when used in conjunction with wainscoting

COPE

To cut or shape the end of a piece of moulding so that it will cover and fit the contour of the piece it's placed against

CORNER BLOCKS

Square blocks used in place of mitering the side and head casings

CORNER GUARDS

Use corner guards to protect the outside edges of a wall from damage

COVE

A moulding with a concave profile used to soften the transition between two planes at right angles to each other. It may be used as a crown around the ceiling or on the inside of a vertical corner as a corner guard

CROWN MOULDING

Also called cornice moulding, it's used to cover the intersection where the walls and the ceiling meet, usually over a large angle. Crown moulding is always installed sprung (angled)



North American
Specialty Laminations™
We've got you covered™

Mouldings Glossary of Terms

DENTIL MOULDING

Moulding featuring a series of small square blocks uniformly spaced and projecting like teeth

DENTIL CROWN

Crown moulding made up of dentil moulding and other moulding types, such as crown and base or base cap, to make up a crown moulding system

DOOR JAMB

The part of a door frame that surrounds and contacts the edges of the stiles and top rail of a door

FINGER JOINT

A piece of wood that has a series of fingers machined on the ends of the two pieces to be joined, which can be meshed; these are held firmly in position by a water-resistant adhesive; these joints are made in a mill and are used to join short lengths together to make longer lengths

FLAT STOCK

Boards with either three or four finished sides for use in shelving, window ledges, a base or casing

FLOOR MOULDING

Also called base shoe or shoe, floor moulding is a narrow moulding that acts as a transition between finished floors and walls or cabinets; it conceals flaws like uneven lines or cracks where the base and floor meet

FRAME

All parts that enclose the window sash or door; vertical members are called side jambs; the top horizontal piece is called the head jamb and the bottom horizontal piece is called the sill

FULL ROUNDS

Rod-shaped millwork used as closet poles, curtain rods and/or towel bars

JAMB

A vertical perimeter frame of a window or door. The most common size for interior use is 1-1/16 inches thick by 4-9/16 inches wide

LATTICE

Thin strips of woven wood, or PVC, surfaced on four sides



North American
Specialty Laminations™
We've got you covered™

Mouldings Glossary of Terms

LINEAL FOOT

One foot of a board or moulding regardless of the width or thickness — also called the running foot; usually this term designates nonspecified lengths

MITER

An angled cut across the end of a lineal part that's usually done to join with a similarly cut part at a corner; an end piece cut at an angle other than a right angle

MOULDING

A narrow strip of wood shaped to a curved profile that's used to accent and emphasize the ornamentation of a structure and to conceal surface or angle joints. Moulding may be exterior or interior

MULLION

Also called the mull. A mullion is the vertical member of a sash, window, or doorframe between openings in a multiple opening frame

PANEL MOULD

A decorative moulding used to trim out raised-panel wall construction

PICTURE FRAME MOULDING

A narrow moulding along the perimeter of the walls near the ceiling line to support hooks for picture hanging. It can be used to make decorative, formal squares on the wall. Picture moulding is also called picture rail moulding or picture frame moulding

PLINTH BLOCK

A decorative block of wood that is thicker and wider than a door casing and used as part of the door trim at the base to enhance the appearance. Plinth block is also called a base block, foot block or pilaster block

PLUMB

Exactly perpendicular or vertical; at right angles to the floor of a structure

PRIMED MOULDING

Moulding with a layer of paint or primer applied to it



North American
Specialty Laminations™
We've got you covered™

Mouldings Glossary of Terms

PVC

Polyvinyl chloride; a plastic material used to make moulded or extruded parts

QUARTER ROUND

Moulding that's one-fourth of a full circle rod and may be used as a base shoe or inside-corner moulding

RABBET

A groove cut in or near the edge of a piece of lumber to fit the edge of another piece. This may be a rectangular recess cut or formed along the long edge of a wood part or a cutout along the end or edge of lumber

ROSETTE

A decorative wood plaque used at the intersection of two materials, secured to a wall and abutted by the end of a stair rail. It may also be used as ornamental decoration at the bottom of windows or doorjambs

SCREEN MOULD

Traditionally used to hold mesh screening into a wood frame. Also good for edge trim on shelving or as wood trim for wallpaper

SOLID MOULDING

Non-finger jointed moulding

SQUARE FOOT

The length of an item in feet multiplied by its width in feet

STOOL MOULDING

A moulded interior trim member serving as a sash or window frame sill cap — these are generally rabbeted

STOP MOULDING

In window trim, a moulding that holds the bottom sash of a double-hung window in place and can also be used as an apron under window stools. In door trim, a stop is nailed to the faces of the doorframe to prevent the door from swinging through the frame

WAINSCOT

A lower-interior wall surface that contrasts with the wall surface above it and is generally 3 to 4 feet in height, often with a chair rail added to its top perimeter and a base around its bottom perimeter

WAINSCOT CAP

A finishing piece for the top edge of wainscoting. May be used with a chair rail to create a larger profile

WALL BASE

A moulding applied around the perimeter of a room along a finished floor; also called baseboard